



How a Backwater Valve Works

BACKWATER VALVE IN OPEN POSITION



BACKWATER VALVE IS OPEN - ALLOWING WASTEWATER TO FLOW TO SEWERS.

BACKWATER VALVE IN CLOSE POSITION



BACKWATER VALVE IS CLOSED - PROTECTING BASEMENT FROM SEWER BACKUPS.